



Alcatel-Lucent OmniTouch™ 8118/8128 WLAN Handset

OmniPCX Office Communication Server User manual



User manual

Introduction

Thank you for choosing a phone manufactured by Alcatel-Lucent.





How to use this guide



Take the call.



Hang up.



2 3 5 6 Alphanumeric keypad.







Apply your choice;. Press the validation key of the navigator or the menu keys.



Use up or down navigation key to navigate in a menu.



Use the left or right navigate key to navigate in a menu.



Use the up and down or left and right navigation keys to navigate in a menu.



Means that the function is subject to programming. If necessary, contact your installer.

These symbols can be supplemented by small icons or text.

Contents

	Getting to know your telephone	p.6
1.)	Display and corresponding icons	p.7
	1.1 Status icons 1.2 MENU icons 1.3 Call icons	р.7 р.7 р.7
2.	Getting started	р.8
	2.1 Installing the battery in the telephone 2.2 Charging your telephone battery 2.3 Switching on your telephone 2.4 Switch off your phone.	р.8 р.9
3.	Using your telephone	p. I
	3.1 Making a call 3.2 Receiving a call 3.3 Calling your correspondent by name (company directory) 3.4 Make a call using the personal phone book 3.5 Redialling 3.6 Make a call-back request to a busy number 3.7 Sending DTMF signals 3.8 Mute, so that your correspondent cannot hear you	p. l p. l p. l p. l p. l p. l
4.	During a conversation	p. I
5.	4.1 Making a second call during a conversation. 4.2 Answering a second call during a conversation. 4.3 Switching between calls (Broker call). 4.4 Transferring a call . 4.5 Transfer a call to the voice mailbox of an absent party 4.6 Three-way conference with internal and/or external correspondents (conference). 4.7 Placing a call on hold (hold). 4.8 Placing an outside call on hold (parking). 4.9 Store a number. 4.10 Adjust audio volume. Sharing. 5.1 Answering the general bell. 5.2 Call pick-up. 5.3 Hunting groups 5.4 Calling a correspondent on his/her loudspeaker. 5.5 Sending a written message to an internal correspondent. 5.6 Send a voice message copy. 5.7 Sending a recorded message to a number / a distribution list. 5.8 Broadcasting a message on the loudspeakers of a station group. 5.9 Modify the automated attendant welcome message remotely.	p.ll p.ll p.ll p.ll p.ll p.ll p.ll p.ll
6.	Keep in touch	p.l
	6.1 Selecting calls to be diverted . 6.2 Diverting calls to another number (immediate diversion). 6.3 Diverting your calls to your voice message service. 6.4 When you return, consult recorded messages 6.5 Activate/disable the personal assistant. 6.6 Personal assistant : reaching you with one number only. 6.7 Forwarding your calls from the receiving terminal ("Follow me") 6.8 Cancelling all diversions 6.9 Diverting calls when your line is busy (divert if busy) 6.10 Do not disturb 6.11 Leaving a recorded message for internal callers 6.12 Consulting written messages 6.13 Message notification	p.11 p.11 p.11 p.11 p.11 p.12 p.22 p.22

Pro	gramming your telephone	22
7.1	Initializing your voice mailbox	2
7.2	Customising your voice greeting p.2	2
7.3	Modifying your personal code p.2	2
7.4	Configuring the telephone ringer	2
7.5	Adjusting your displayp.2	13
7.6	Screensaverp.2	14
7.7	Selecting language	4
7.8	Selecting connection language, profiles and settings menus p.2	14
7.9	Programming your personal directory	4
7.10	Programming an appointment reminder p.2	25
	Lock / unlock your telephone p.2	
	Activate/deactivate the Key tones	
7.13	Activate/deactivate the Warning tones p.2	16
Mer	nus tree p.2	27
Gua	rantee and clauses	29

Getting to know your telephone

- Adjust audio volume (short press)
- Activate/deactivate loudspeaker (during a conversation) Long press OmniTouch 8128 WLAN Handset
- Mute key so that your correspondent can no longer hear you (long press)

Access MENU



'Menu' key is used to access various functions of the set (programming, operation, etc.)



'OK' key to access the set local configuration (ringing, contrast, etc.), apply your choice.

Status icons



Battery charge level



Radio reception quality



Programmed call-back time



Lock / unlock your telephone



Notification



Call diversion activated



Handfree mode activated



New voice or text message, call back request, missed calls



Silent mode activated



Headset connected

Push To Talk (OmniTouch 8128 WLAN-Handset - OmniPCX Enterprise)

Display key.

Used to access various functions according to the status of the telephone (communication, text entry, idle, ...). Example:



to access the 'Redial' function



apply your choice



to access more options



o access more options



to correct a character entered



to end a configuration or to go back to the previous page or to the idle screen

Take the call

Switching between calls (Broker call) - single-line terminal

To lock the keypad (long press)

Profile button

This key allows you to select a profile (volume, ring tones, vibration, key sound) or to create a new profile.

Alcatel-Lucent (1)

Back-lit screen

The screen switches off automatically after a few seconds. The display is in color for the OmniTouch 8128 WLAN Handset. The screen switches on automatically as soon as you press any key.

Headset socket

Customizing the telephone:



'OK' key to access the set local configuration (ringing, contrast, etc.)

Apply



used to validate your choices and options while programming or configuring

Navigate



Navigation keys: used to navigate the menus or in a text field when entering characters

Switch on / off (long press)

Hang up

Return to first screen

Switch off ringer

Company directory (long press)

OmniTouch 8128 WLAN Handset

Microphone

* of 0. # CB

1 Display and corresponding icons

1.1 Status icons

The status icons are displayed on the welcome screen and indicate the status of the telephone.



Battery charge level



Radio reception quality



Programmed call-back time



Lock / unlock your telephone



Notification



Call diversion activated



Handfree mode activated



New voice or text message, call back request, missed calls



Silent mode activated



Headset connected

1.2 MENU icons



The MENU is accessible from the welcome screen by pressing the \mathbf{OK} key.

It provides access to all the local functions available on your phone.



Profile (volume, ring tones, vibration, key sound).



Handset settings (such as automatic key lock, display, device info).



Handset connection configuration.

1.3 Call icons

Ple

Call in progress



Incoming call



Call on hold

2

2.1 Installing the battery in the telephone

Installing the battery in the telephone







While maintaining the battery module in position, slip the lock to the locked position



Check that the battery module is properly installed in its housing

To remove it



Slip the lock to the unlocked position



Lift the battery module



You can then remove the battery module

2.2 Charging your telephone battery



It is important to fully charge your phone before using it for the first time..

Connect the charger and place the telephone in the charging holder. The phone LED is orange when charging.



Take the phone out of the charger.

Once the phone is charged (steady green), you can take the phone out of the charger. To remove the phone from the charger, you must first tilt it forward and then take it out of the charger.



Rack charger.



8

Battery rack charger.





The battery charge time is 2.5 hrs.

The indicator LED on the set gives the following indications:

	-
None	Switched off
Green, steady	Handset fully charged and in charger
Green, flashing	Switched on, and not in charger
Orange, steady	Charging
Orange, flashing	Low battery
Red, flashing	Very low battery

2.3 Switching on your telephone



Switch on (long press)

Vait a few seconds (about 3s).

If the display fails to light or the red LED is flashing, recharge the battery

If the red LED is flashing slowly:

- Check that you're in a WIFI hotspot
- Check that the telephone is properly installed in the system (consult the PABX manager).

2.4 Switch off your phone



Select the incoming call.



To confirm.

3 Using your telephone

3.1 Making a call











dial directly the number for your call

number required long press (Handfree)

number required



Only the OmniTouch 8128 WLAN Handset allows the handsfree mode.



To make an external call, dial the outside line access code before dialling your correspondent's number. 9 is the default code for an outside line.



For the operator, dial '0' (by default).

3.2 Receiving a call












3.3 Calling your correspondent by name (company directory)









press the 'Call by name ' key

first letters of your correspondent's name*





select the name from the displayed list



 $\,^*$ You enter your contact's name in predictive text mode. In this mode, enter each letter of the name by pressing only once on the key with this letter.

3.4 Make a call using the personal phone book









select the contact to call start the call

3.5 Redialling

Call back on the last 10 number dialled









select the No. in start the call the last ten issued

3.6 Make a call-back request to a busy number

the number you are calling is busy







Using your telephone

3.7 Sending DTMF signals

During a conversation you sometimes have to send DTMF signals, such as with a voice server, an automated attendant or a remotely consulted answering machine.




to activate




3.8 Mute, so that your correspondent cannot hear you

You can hear your correspondent but he/she cannot hear you:



4 During a conversation

4.1 Making a second call during a conversation



4.2 Answering a second call during a conversation

In conversation
Incoming call
Call on hold

• A second correspondent is trying to call you:



Display the name or number of the second call:



Select the incoming call

Answer the second call:



• To return to your first caller and end the conversation in progress:



Take the call

4.3 Switching between calls (Broker call)


During a conversation, a second call is on hold. To accept the second call:



During a conversation

4.4 Transferring a call

To transfer your call to another number:





You can also transfer your call immediately, without waiting for your correspondent to answer.



Transfer between two outside calls is not generally possible (depends on country concerned and system configuration).

4.5 Transfer a call to the voice mailbox of an absent party

During the call, you want to transfer your correspondent to the voice mailbox of another correspondent.



enter the voicemail number

Three-way conference with internal and/or external correspondents (conference)

During a conversation, a second call is on hold:



Cancel the conference and remain with your second correspondent (your first call is placed on hold):



Hang up on all correspondent:



After the conference, to leave your two correspondents talking together:



4.7 Placing a call on hold (hold)



• Exclusive hold:

During a conversation, you wish to place the call on hold and recover it later, on the same telephone.



Recover the call on hold:



Take the call

During a conversation

4.8 Placing an outside call on hold (parking)



You can place an outside call on hold and recover the call on another telephone:



• To recover the parked call:







number of telephone from which call was parked



If the parked call is not recovered within a preset time (default value 1 min 30), it is transferred to the operator.

4.9 Store a number

During a call, to save the number onto a call key:



select the key to programme (0 to 9)



your

correspondent*

 $[\]ensuremath{^{*}}$ Enter the name of your correspondent :



enter the text: the number pad keys have letters that you can display by successive presses ((the letter Q is on key 7 and the letter Z is on key 9))



position the cursor in the entry field





erase last character entered

4.10 Adjust audio volume

During a call, to adjust the volume level of the loudspeaker or receiver:









Adjust audio volume


5 Sharing

5.1 Answering the general bell



When the operator is absent, outside calls to the operator are indicated by a general bell. To answer:





5.2 Call pick-up



You hear a telephone ringing in an office where no-one can answer. If authorised, you can answer the call on your own telephone.

• If the telephone ringing is not in your pick-up group:







number of telephone ringing



The system can be configured to prevent call pick-up on certain telephones.

5.3 Hunting groups



• Hunting group call:

Certain numbers can form a hunting group and can be called by dialling the group number.





no. of group to be called

• Temporary exit from your hunting group: / Return into your group:





'leave group ' programmed key your group number

Belonging to a group does not affect the management of direct calls. A specific telephone within a group can always be called by using its own number.

5.4 Calling a correspondent on his/her loudspeaker



Your internal correspondent does not answer. If authorised, you can remotely activate your correspondent's phone:



you are connected to the loudspeaker on your correspondent's phone (if he/she has the hands free function)

5.5 Sending a written message to an internal correspondent









number to be called

Predefined message



Select the message to be sent

Sharing







enter the no. of the apply your message to be sent choice (01 to 27)

Change language of message



change language of message

Personal message







create a temporary personal message*

send message

^{*} create a temporary personal message :



enter the text: the number pad keys have letters that you can display by successive presses



position the cursor in the entry field;





erase last character entered




enter a digit (keys 0 to 9): Select a digit (keys 0 to 9): the digit can be accessed after all the characters of the key pressed have been displayed on the screen.

• The 27 standard messages are shown below:


П	Call me back	15	Meeting on (*)
2	Call me back tomorrow	16	Meeting on at _:_ (*)
3	Call me back at _:_ (*)	17	Out for a while
4	Call back (*)	18	Absent for the rest of the day
5	Call the attendant	19	Absent, back at _:_ (*)
6	Call the secretary	20	Absent, back on at _:_ (*)
7	I will call back at _:_ (*)		On vacation, back on (*)
8	Use paging	22	External meeting
	Please fetch your fax	23	External meeting, back on (*)
10	Please fetch your mail	24	I am in room nr (*)
П	Please cancel your forwarding	25	In a meeting - do not disturb
12	Visitors are waiting	26	At lunch
13	You are expected at reception	27	Indisposed
14	Meeting at _:_ (*)	(*)	Messages to be completed using numeric keypad

5.6 Send a voice message copy



Sharing

5.7 Sending a recorded message to a number / a distribution list



5.8 Broadcasting a message on the loudspeakers of a station group

A message not requiring an answer can be broadcast on the loudspeakers within your broadcast group:




broadcast group

The message will only be broadcast on terminals not in use and which have a loudspeaker.


5.9 Modify the automated attendant welcome message remotely

This feature enables a user with the appropriate rights to modify the automated attendant night or day-time message.




6.1 Selecting calls to be diverted


When a diversion is applied, you can select the types of call to be diverted: outside, internal, all.



5.2 Diverting calls to another number (immediate diversion)

The number can be your home, portable or car phone, voice message or an internal extension (operator, etc.).






6.3 Diverting your calls to your voice message service




6.4 When you return, consult recorded messages

The display of the 'envelope' icon indicates that there is a message present.




Listen to message


The sign '*' indicates a message not consulted.




6.5 Activate/disable the personal assistant



6.6 Personal assistant: reaching you with one number only






6.8 Cancelling all diversions



6.9 Diverting calls when your line is busy (divert if busy)


Callers can be diverted to another telephone if you are already on the line.



Do not disturb 6.10

You can make your terminal temporarily unavailable for all calls.





Leaving a recorded message for internal callers

You can leave a message on your terminal which will be displayed on the screen of the terminal calling you.



Predefined message




select the message to be sent



enter the no. of the message to be sent (01 to 27)

Change language of message



change language of message

Personal message



* create a temporary personal message :





create a temporary personal message*

send message



Enter the text: the number pad keys have letters that you can display by successive presses.



Position the cursor in the entry field.





Erase last character entered.



Select a digit (keys 0 to 9): the digit can be accessed after all the characters of the key pressed have been displayed on the screen.

The 27 standard messages are shown below:

I	Call me back	15	Meeting on (*)
	Call me back tomorrow	16	Meeting on at _:_ (*)
3	Call me back at _:_ (*);	17	Out for a while
4	Call back (*)	18	Absent for the rest of the day
5	Call the attendant	19	Absent, back at _:_ (*)
6	Call the secretary	20	Absent, back on at _:_ (*)
7	I will call back at _:_ (*)	21	On vacation, back on (*)
8	Use paging	22	External meeting
9	Please fetch your fax	23	External meeting, back on (*)
10	Please fetch your mail	24	I am in room nr (*)
П	Please cancel your forwarding	25	In a meeting - do not disturb
12	Visitors are waiting	26	At lunch
13	You are expected at reception	27	Indisposed
14	Meeting at _:_ (*)	(*)	Messages to be completed using numeric keypad

6.12 Consulting written messages


The light indicates that messages have been received.






select the message to consult

During the display of the information:



During message consultation, press the 'menu' key to access the following functions: (Menu



6.13 Message notification

A message is left in your mailbox but you are not at your desk. You can configure your telephone so that you receive notification of the message on another telephone.



Activate/deactivate message notification



Enter the number of the set where the notification is to be received



Change the time slot

The time slot during which notification is activated can be changed.



7.1 Initializing your voice mailbox





Your personal code is used to access your voice mailbox and to lock your telephone.


7.2 Customising your voice greeting

You can replace the greeting message by a personal message





During the recording of a message, it is possible to access the following functions: (



7.3 Modifying your personal code

Your personal code is used to access your voice mailbox and to lock your telephone.











old code (4 digits)

new code (4 digits)

display requests confirmation of new password



As long as your voice mailbox has not been initialized, personal code is 1515.

7.4 Configuring the telephone ringer





profile button




select the profile (silent, vibrating ringer, low, loud or customized)







Adjusting the screen brightness




Adjusting screen contrast: (only for OmniTouch 8118 WLAN Handset)




choose brightness

7.6 Screensaver (only for OmniTouch 8128 WLAN Handset)



7.7 Selecting language









select the language of your choice


apply your choice

7.8 Selecting connection language, profiles and settings menus



selecting language

7.9 Programming your personal directory



Programming an appointment reminder

You can define the time of a temporary reminder (one in 24 hours) or a permanent reminder (every day at the same time).

Program a temporary reminder call.







enter time of appointment

Program a permanent reminder call.







enter time of

appointment



select the type of appointment (temporary or permanent)

Enter the reminder time.



enter the reminder time















enter the reminder time

select the type of appointment (temporary or permanent)

At the programmed time, your telephone rings.







Lock / unlock your telephone

Lock / unlock your telephone.



enter your personal password

Unlock your phone.





enter your password to unlock your set (default 0000)

Locking the keypad.



Long press

Lock the keypad automatically.
 You can configure your set so that the keypad is blocked automatically after 5, 10 or 20 seconds.





Unlocking the keypad.



7.12 Activate/deactivate the Key tones

By default the set emits a tone each time a key is pressed. To deactivate these tones:





choose the type of key sound

7.13 Activate/deactivate the Warning tones

The warning tones inform the user of an abnormal operation (out of range, system activated or halted, etc.). To deactivate these tones:





Menus tree



The wording is not contractual and may be subject to change..

System menu items

- 1	2	3	4	5	6
menu	Settings	My phone	Directory		
			program		
			Language Password		
		My samileas	Consultation	Forward services	Immediate forward
		My services	Consultation	roi wai d sei vices	Forward on busy
					Fwd on no reply
					Fwd busy/no reply
					Deactivate forward
					Deactive follow me
					Remote forward
					Deact remote fwd
				Don't disturb-Lock	
					Do not disturb
					Suite: DND
				Call pick up	Group call pick up
					Set call pick up
					Night call pick up
					Park/retrieve call
					Common hold
					ProcessGrp pick up
					Group call pick up
				Associate services	Call associate
					Overflow to associate
					Overflow if busy
					Cold River
					Deact ovflow to assoc
				Consult-Callbacks	Last caller
					Charging info
					Alarm consultation
				Appointment	
				VoiceMail services	Notify voice msgs
				Send voice message	
				Misc. services	Intrusion protection
					Business account code
				Substitution	
				Enter hunting group	
					Leave hunting grp
					Set out of service
					Meet-me conference
			Z behind UA prefix		

Associate Call mode My parameters IP parameters Version Phone test Redial list Appointment Lock Messaging Voice mail Text mail No callback No unanswered No last caller call No unanswered No unanswered Redial list Immediate forward Forward Other forward Forward on busy Fwd on no reply Fwd busy/no reply Remote forward Deactive follow Deact remote fwd Predefined Forward to text message Msg to complete Message to create Do not disturb **Events** No last caller No unanswered No unanswered int Redial list No outgoing call Personal directory

2

3

4

Principal line Secondary lines Auto conference Announce system Manual conference Ivory tower Priority call; CUG

6

Radio paging Transparency

5

Pulse signalling DTMF signalling Connect Alphapage

27

Menu tree

Connections menu items

2 3



Standard Headset

Network

In charge No action Charge profile

Profiles menu items

2



Normal

Silent

Vibrate

Loud Soft

Add new

Settings menu items

5



Sound & Alerts Volume

Ring signals Vibrating alert Key sound

Battery warning

Locks Automatic key lock

Display Brightness

Screen saver Black

Information Not used Message

Appointment Notification Terminal lock

Keypad lock

Language

Device info Software

Hardware WLAN info Network info TPTP info

Guarantee and clauses

Independently of the legal warranty that covers this appliance, it is guaranteed for I year, parts and labour, counting from the date indicated on your invoice.

The invoice will be demanded if making a claim under the warranty. The warranty does not however apply in the following cases: in the event of use that does not comply with the instructions given in this user's manual, faults or damage caused by natural wear, damage resulting from a cause external to the appliance (e.g. impact, fall, exposure to dampness, etc.), noncompliant installation or modifications or repairs carried out by people who are not approved by the manufacturer or retailer.

Warning: never place your telephone in contact with water. To clean your telephone, you may however use a damp soft cloth. Never use solvents (trichlorethylene, acetone, etc.) which may damage the plastic parts of your telephone. Never spray it with cleaning products.

The ear piece and microphone area of the handset may attract metallic objects that may be dangerous for the ear.

The wording is not contractual and may be subject to change. Some functions of your telephone are controlled by a software key and the configuration of the unit.

Declaration of compliance

EC countries: we, **Alcatel-Lucent Enterprise**, declare that the Alcatel-Lucent OmniTouch 8118/8128 WLAN Handset products comply with the essential demands of Directive 1999/5/CE of the European Parliament and Council. A copy of the original of this declaration of compliance can be obtained from your installer.



Information relative to the environment

This symbol indicates that at the end of its life, this product should be subject to special collection and disposal in member countries of the European Union, as well as in Norway and Switzerland. By ensuring this product is disposed of correctly, you will help to conserve natural resources and help prevent potential negative consequences to the environment and human health which could otherwise be caused by inappropriate disposal of this product. For further

details about recycling this product, please contact the supplier who sold you the product.

Alcatel-Lucent Enterprise, in keeping with its policy of constant product improvement for the customer, reserves the right to modify product specifications without prior notice.

Alcatel, Lucent, Alcatel-Lucent and the Alcatel-Lucent logo are trademarks of Alcatel-Lucent.

All other trademarks are the property of their respective owners.

The information presented is subject to change without notice.

Alcatel-Lucent assumes no responsibility for inaccuracies contained herein.

Copyright © 2010 Alcatel-Lucent. All rights reserved.

